

Tableau de compatibilité Postes/Micros

POSTES CB EMISORES CB	Micro DNC 518 6 br / pins	Micro DNC 518 U/D 6 br / pins	Micro DNC 520 6 br / pins	Micro DNC 520 U/D 6 br / pins	Micro DIN 5 br / pins	Micro 4 broches 4 pins	Micro 6 broches 6 pins	Micro Jimmy 4 br / pins	Liberty Mic 6 br / pins	Micro/HP RJ45 William	Micro VOX mains-libres manos libres
RÉF.	ACFD124	ACFD126	ACFD521	ACFD520	-	ACDC004	-	ACFD200	TXMU000	ACFD093	ACDC200
George	■	■					■		■		
Grant Classic*	■	■				■	■		■		
Grant II			■	■					■		
Harry & Harry ASC			■	■					■		
Harry Classic			■	■					■		
Harry II ASC			■	■					■		
Harry II Classic			■	■					■		
Harry III ASC			■	■					■		■
Henry ASC Classic			■	■					■		
Herbert*	■	■				■	■		■		
Herbert New	■	■					■		■		
J.F.K.*	■	■				■	■		■		
J.F.K. Classic*	■	■				■	■		■		
J.F.K. II			■	■					■		■
Jackson*	■	■				■	■		■		
Jackson II			■	■					■		■
James	■	■					■		■		
Jimmy								■	■		
Jimmy II			■	■					■		
Johnny & Johnny ASC			■	■					■		
Johnny II			■	■					■		
Johnny III			■	■					■		■
Johnson	■	■					■		■		
Johnson Classic	■	■					■		■		
Johnson II ASC			■	■					■		
Kenji									■		
Lincoln II			■	■					■		■
Ninja									■		
Taylor					■				■		
Taylor II Classic			■	■					■		
Taylor III ASC			■	■					■		
Taylor New	■	■					■		■		
Teddy			■	■					■		
Tommy			■	■					■		
Thomas									■	■	■
Truman			■	■					■		
Valery Classic*	■	■				■	■		■		
Walker			■	■					■		
William									■	■	■
Wilson*	■	■				■	■		■		

* vérifiez le nombre de broches micro de votre version / ■ Compatible mais sans la fonction Up/Down / ■ Compatible